


## Hangar Measurements & Amenities



Hangar Row	A	B	C	D	Door Height	Doors/Utilites
A	40'	32'10"	18'10"	20'3"	11'6" to 12'6"	Electric Doors
B	40'	33'	18'10"	20'	11'6" to 12'6"	Electric Doors
C	40'	31'4"	15'4"	14'4"	10'	Manual Doors
D	40'	31'4"	15'4"	14'4"	9'	Manual Doors
E	40'	31'4"	15'4"	14'4"	9'	Manual Doors
F	40'	31'4"	15'4"	14'4"	9'	Manual Doors
K 1,5	56'	62'	41'	42'	16'	Electric Doors, Heated (tenant utilities)
K 2,4	56'	41'	21'	28'	16'	Electric Doors, Heated (tenant utilities)
L	40'6"	32'7"	18'6"	20'	12'6"	Electric Doors
M - North	55'	32'7"	20'8"	27'	15'6"	Electric Doors
M - South	55'	40'6"	25'8"	27'6"	15'6"	Electric Doors
N	43'6"	36'4"	18'4"	21'6"	14'6"	Electric Doors (8,9,10,11 have Heat)
O	43'4"	36'	21'5"	18'	15'8"	Electric Doors
P	40'6"	32'6"	18'6"	19'10"	12'6"	Electric Doors
Q	43'2"	35'9"	17'8"	21'	16'	Electric Doors
R 1,2,& 3	55'6"	62'	62'	55'5"	18'	Electric Doors, Heated (tenant utilities)
R 4	64'6"	62'	62'	64'5"	18'	Electric Doors, Heated (tenant utilities)
S 1,2,4-9	41'6"	33'	18'	21'	12'	Electric Doors
S 3	41'6"	33'	18'	21'	12'	Electric Doors (no heat)
T	60'	62'	62'	60'	18'	Electric Doors, Heated (tenant utilities)
U	56'	48'	24'	28'	16'	Electric Doors, Heated (tenant utilities)
V	41'6"	31'	21'	20'	11'6"	Electric Doors, Heated (tenant utilities)
W	41'6"	31'	21'	20'	11'6"	Electric Doors, Heated (tenant utilities)
5820	60'	62'	62'	60'	18'	Electric Doors, Heated (tenant utilities)
5822	60'	62'	62'	60'	18'	Electric Doors, Heated (tenant utilities)

### Notes to user

Every effort is made to keep this list up to date.

Please use this list only as a reference.

Verify information by contacting Airport Administration:

T: 402-458-2400

[administration@lincolairport.com](mailto:administration@lincolairport.com)